


D-Link Technical Support Setup Procedure

How to view the DCS-2121 camera remotely

Step 1: Open a web browser such as Internet Explorer, Mozilla Firefox or Safari. On the address bar of the web browser type in there the IP Address of the camera server and then hit the Enter key on your keyboard.



*** Note: For you to check the IP Address of the camera. Please do check set-up procedure on how to check the camera's IP Address.

Step 2: After typing the IP Address of the camera on the address bar of the browser, a username and a password will appear. In default settings the username is "admin" and then leave the password field blank, then click on OK button.




Step 3: Click on the Setup Tab, Network set-up on the left hand side and put a check mark on "Enable UPnP Port Forwarding". Under the External HTTP port it is set default as port 80 and port 554 for External HTTP port 554.

*** Note: Take note of this External HTTP port and the External RTSP port because you will need this information in doing Port Forwarding on you router. Please refer to the Next Step in Port Forwarding.



Step 4: Open a web browser such as Internet Explorer, Mozilla Firefox or Safari. On the address bar of the web browser type in there the IP Address of the router and then hit the Enter key on your keyboard.



*** Note: For you to check the IP Address of the router. Please do check set-up procedure on how to check the camera's IP Address.

Step 5: After typing the IP Address of the router on the address bar of the browser, a username and a password will appear. In default settings the username is "admin" and then leave the password field blank, then click on OK button.

Step 6: Click on the Advance Tab, then click on the Virtual Server on the left hand side.

- 1. Put a check mark on the tick box
- 2. Enter a name to identify the device name for the specific port
- 3. Input the IP Address of the DCS-2121 camera
- 4. Input the http port set for the camera
- 5. Save the settings



*** Note Port forwarding section may differ depending on your routers configuration page. Contact your router manufacturer for port forwarding configuration. Once you've contacted your router manufacturer give them the IP Address of the camera and the External HTTP port and the External RTSP port.


Here's an example that you need to provide to your routers manufacturer

IP address: 192.168.xxx.xxx (Camera's IP Address)

HTTP Port: 80 TCP

RTSP Port: 554 TCP and UDP

Step 5: Check the Public IP Address of the router under the Status Section



Step 6: Open the web browser by typing in "http://publicip:httpport

Example: http://192.168.24.197:80

